

POWER STATION

EASY START GUIDE

1 CONNECTING POWER SUPPLY TO STATION



POWER INPUT

WAHL LOGO GLOWS

WAHL Correct power supply is connected

WAHL Incorrect power supply is connected

2 CHARGING YOUR DEVICES

5V CHARGING DOCKS



USB-C OUTPUT